

***MICHELIN***  
***INFLATABLE SOLUTIONS***

***MOVIE SCREEN***



***INSTRUCTION MANUAL***



---

This file contains all our recommendations to guide you in the use of your new Michelin Inflatable Solutions product.

We recommend that you read it very carefully the first time you use it, and refer to it if you have any doubts.

Our sales team remains at your disposal for any further information (e-mail: [commerce@aircaptif.com](mailto:commerce@aircaptif.com)).



# CONTENTS

---

I. Checking the contents of the delivery	4
II. Legend	5
III. Features	6
IV. Installation	7
V. Dismantling	10
VI. Maintenance	11
VII. Warranty conditions	13




# I - VERIFICATION OF CONTENTS ON DELIVERY

## Elements included in a PACK :

- 1x carry bag (A)
- 1x inflatable structure + projection canvas (B)
- 1x high flow pump (C)
- 4x stakes (D)
- 4x guy ropes (E)


## Optional elements:

- 1x repair kit (F)

**(A)****(B)****(C)****(D)****(E)****(F)**



## II - LEGEND



Lower crown, plug without non-return valve for deflation

Upper crown, plug with non-return valve for inflation

Inflate/deflate non-return plug



"Clamp" open: allows air to pass through (position when inflating/deflating)



"Clamp" closed: does not allow air to pass through (position when inflating/deflating)"



### III - CHARACTERISTICS

Width screen	Height screen	Structure width	Structure height
3 m	1,70 m	3,30 m	2,5 m
4 m	2,20 m	4,40 m	3,40 m
5 m	2,80 m	5,3 m	4 m
6 m	3,40 m	6,5 m	5 m
8 m	4,50 m	8,70 m	6,6 m

6



## IV - INSTALLATION

Installation takes around 15 minutes, including inflation.

### 1- Remove the screen (structure + fabric) from its carry bag



### 2- Laying out the inflatable on the ground

The more the structure is spread out, the faster it inflates. Spread it out, making sure the white fabric is on top to avoid damaging it.



7

### 3- Close all the plugs and open all the clamps on the pipes.

Make sure that all valves are securely closed before you start inflating. And that all the clamps are open.

Each structure is made up of several inflatable bladders connected together by tubes that can be closed using clamps.

Together they form the **"OnePump" system**.

This system allows you to inflate the module at a single point (when the clamps are open), but also to block the propagation of any loss of pressure on one of the tubes (when the clamps are closed)..







## IV - INSTALLATION

### 4- Inflating the structure

To inflate quickly and optimally, open all the clamps. Once inflation is complete, close all the clamps.



**The air passes**



**The air can't get through**

The inflation valve is accessible at the bottom right of the screen (see photo). Loosen the top cap.



8

Start inflation by pressing the pump's "main motor" mode (orange button), allow the air to spread for 1 to 2 minutes and then press the pump's "boost" mode (red button) to continue inflation.



Then



The structure is inflated when it is rigid. You can then turn off the pump and close all the clamps.





## IV - INSTALLATION

### 5- Installing the ropes


Fit the guy ropes to the 4 rings provided: 2 rings under the screen and 2 rings above the screen, then lift the structure using the ropes.



### 6- Rigging the structure

Brace the screen with the stakes, as shown in the diagrams below.

9





## V - DISMANTLING

### 1- Deflate the structure

Place the screen flat on the floor and **unscrew the lower crown** of the bottom right-hand cap to deflate the structure.

Then leave the air to evacuate on its own for around ten minutes.  
For faster deflation, you can unscrew the plugs behind the screen, taking care not to damage the projection screen fabric.



### 2- Folding the screen

10

For optimum folding, first fold the screen in half, fold in half again and then fold lengthways.

*(see photos below)*



Finally, slide the folded structure into the bag.



## VI – MAINTENANCE

---

### 1- Uses involving risks

- ✓ Do not use machinery or sharp equipment near the screen, as this could damage it.



- ✓ Do not use abrasive ballast (breeze block, stone, metal), as this may cause premature damage to the perimeter of the shelter.



- ✓ Do not bring the shelter into contact with flammable or corrosive products, as this may damage the structure.





## VI – MAINTENANCE

---

### 2- Maintenance tips

Covers should be folded appropriately to maintain their watertight properties and prevent damage during storage.

You can hose down the shelter (avoid pressure washing). **Wait for the shelter to dry before storing it in the transport bag.**

Inflation is guaranteed for 48 hours. Before each use, check the inflation.

**A repair kit is included in your PACK.** In the event of an inner tube leak, remove the tube from the textile sleeve, paying attention to the eyelets at the ends.

12

These "eyelet" fasteners take the form of transparent plastic caps.

Clean the leak area with rubbing alcohol and leave to dry for 1 minute. Finally, apply the self-adhesive patch, pulling the bladder taut. Press the patch back and forth until it adheres, then replace the bladder in the textile sleeve, fastening the ends securely.

To ensure that the repair is complete, perform an initial inflation by isolating the freshly repaired bladder from the rest of the structure.





## VII - WARRANTY CONDITIONS

---

The AirCaptif guarantee lasts for one (1) year.

This guarantee covers the following defects:

Leaks from a defective weld.

Valve detachment or valve leakage.

The guarantee does not cover damage resulting from incorrect assembly, incorrect use or resulting from an external cause such as :

Normal wear and tear of components.

Damage due to external aggression.

Damage caused by transport, malicious damage, poor maintenance and in particular cleaning with unsuitable products (please refer to our assembly instructions), falling trees, etc.

To benefit from the guarantee, please send us a photo of the product with the reference number or a copy of your invoice to:

**[commerce@aircaptif.com](mailto:commerce@aircaptif.com)**.

Please note that the commercial guarantee does not deprive you of the provisions relating to the guarantee against hidden defects (articles 1641 et seq. of the French Civil Code) or the legal guarantee of conformity (L211-1 et seq. of the French Consumer Code).

The guarantee is limited solely to the replacement of parts (excluding labour) recognised as defective by our company, without any compensation or damages being claimed for material or physical damage caused.

In the event of a return, the following information must appear on the packaging: Name and address of the sender Name and address of the user Number of our delivery note, invoice, quotation, dimensions of the shelter, reasons for the return.





## VII - WARRANTY CONDITIONS

---

When acting under the legal guarantee of conformity, the consumer :

- ✓ has a period of two years from the date of delivery of the goods in which to take action
- ✓ may choose between repairing or replacing the goods, subject to the cost conditions set out in article L. 211-9 of the Consumer Code
- ✓ is exempt from having to prove the existence of a lack of conformity in the goods during the six months following delivery of the goods. This period is extended to twenty-four months from 18 March 2016, except for second-hand goods.

The legal guarantee of conformity applies independently of any commercial guarantee that may have been granted.

14

Consumers may also decide to invoke the warranty against hidden defects in the goods sold, as defined in article 1641 of the French Civil Code. In this case, they may choose between rescission of the sale or a reduction in the sale price in accordance with article 1644 of the French Civil Code.

Article L. 211-4 of the French Consumer Code: "The seller is obliged to deliver goods in conformity with the contract and is liable for any lack of conformity existing at the time of delivery. He shall also be liable for any lack of conformity resulting from the packaging, the assembly instructions or the installation when the latter was made his responsibility under the contract or was carried out under his responsibility".

