



OWNER'S MANUAL

Passenger and Light Truck Tire
Limited Warranty, Registration Card,
Safety and Maintenance Tips

IMPORTANT!

Register your tires at uniroyal.ca
or send us your tire registration card by mail.
See the fold-out after page 21.

Thank you for choosing Uniroyal® tires. With proper tire maintenance and care, you will enjoy driving on your new Uniroyal® tires for a long time.

Please be sure to visit uniroyal.ca to find out how and why to register your new Uniroyal tires. While you're there, check out our Tire Care and Driving Tips section to take full advantage of your new tires.

INDEX

Alteration 14

Contact Us 18

Controllability 6

Customization 14

DOT 16

High Speed Driving 8

How to Read a Sidewall 9

Inflation 6 - 8

Mounting 16

Overload 12

Repairs 15

Rotation 13

Service Life 17

Speed Ratings 9 - 10

Spinning 8

Storage 15

Temporary Spares 16

Tire Failure 6

Tire & Wheel Inspection 11

Tire Mixing 13

Trailer Towing 12

Warranty 2

Wear Bars 12

Wheel Alignment 12

Wheel Balance 12

Winter Driving 13

UNIROYAL® PASSENGER AND LIGHT TRUCK TIRE LIMITED WARRANTY

To ensure your understanding of and compliance with the terms and conditions of this warranty, please read it carefully. It is essential that you also read and understand the safety and maintenance recommendations for tires contained in this Owner's Manual.

This warranty covers the original purchaser of Uniroyal® passenger and light truck tires.

WHAT IS COVERED AND FOR HOW LONG

Uniroyal passenger and light truck tires that are used in normal service on the vehicle on which they were originally fitted are covered as follows:

Workmanship and materials

If there is a defect in workmanship and materials during the life of the original usable tread, or six years from date of purchase (whichever comes first), your tire may be replaced on a pro rata basis under this warranty. After six years or the wear of the original usable tread, whichever occurs first, all warranties, expressed or implied, expire.

The "date of purchase" refers to the date on your sales invoice. If you cannot find your sales invoice, the date will be calculated based on the date of manufacture which is molded on the sidewall of your tire.

The "life of the usable tread" refers to the original tread worn down evenly across the face of the tread to the level of the treadwear indicators, which is 2/32nds of an inch (1.6 mm) of tread remaining. Uneven wear is defined as a tread groove difference of 2/32nds of an inch or more across the face of the tread on the same tire.

Treadwear

If the tire treadwear does not reach its mileage warranty a pro rata replacement of the tire may be available under this warranty. For the mileage warranty associated with a specific tire, please see your Uniroyal tire retailer or visit uniroyal.ca.

In order to maintain the treadwear warranty on your tires, the tires must be rotated every 10,000 to 12,000 km, or as recommended by the vehicle manufacturer, whichever rotation period is less. Failure to rotate the tires as provided herein voids the treadwear warranty.

Note that if you use different size tires on the front and rear axles, your tires cannot be rotated as recommended by Uniroyal. As a result, the mileage warranty on each rear tire will be half that specified.

WHAT IS NOT COVERED

This warranty does not cover tires damaged due to misuse, abuse or accident such as:

- Road hazard injury (e.g., a cut, snag, bruise, impact damage or puncture);
- Incorrect mounting of the tire, tire/wheel imbalance or improper repair;
- Misapplication, improper maintenance, racing, underinflation, overinflation or other abuse;
- Uneven or rapid wear which is caused by mechanical irregularity in the vehicle such as wheel misalignment, (a measured tread difference of 2/32nds of an inch or more across the tread on the same tire);
- Accident, fire, chemical corrosion, tire alteration or vandalism;
- Flat spotting caused by improper storage or brakelock;
- The addition of liquid, solid or gaseous materials other than air, nitrogen or carbon dioxide (for example, waterbase sealers or balancing substances);
- Minor cosmetic ozone or weather cracking;
- Use of Uniroyal® tires that is inconsistent with the safety and/or maintenance information provided in your Owner's Manual.

Other limitations include but are not limited to the following:

- Failure to rotate your tires as recommended by Uniroyal voids the treadwear warranty.
- The mileage warranty on each rear tire will be half that specified for tires that cannot be rotated as recommended by Uniroyal because the tire size on the front axle of the vehicle is different from that on the rear axle.
- No treadwear warranty for tires used in commercial applications (such as mail carrier, taxi cab or ride sharing vehicles).
- DOT-approved competition tires are excluded from any mileage warranty.
- Motor Tricycle vehicles are excluded from treadwear mileage warranties.
- Winter tires must be used during winter months only. These include the months of September through April, defined as a period beginning on or after September 1 of a given year and ending no later than April 30 of the following year. Uniroyal winter tires require documentation of the timing of the installation and removal of the tires each winter to maintain coverage under the limited warranty for treadwear.
- No treadwear warranty for tires delivered as original equipment on your vehicle.
- You must be the original purchaser of tires to participate in the Treadwear Warranty.

WHAT WILL UNIROYAL® DO?

Workmanship and materials

If a tire is covered, and 2/32nds of an inch (1.6 mm) or less of the original tread is worn (or 25% or less, whichever is more beneficial to you), and it is within 12 months of the date of purchase, Uniroyal will, free of charge, replace your tire with a comparable new Uniroyal® replacement tire, mount the tire, and balance the tire. You must pay the cost of any other service charges and applicable taxes.

If a tire is covered, and more than 2/32nds of an inch of original tread has been worn (or more than 25%, whichever is more beneficial to you), or it has been more than 12 months from the date of purchase, Uniroyal will replace the tire with a comparable new Uniroyal replacement tire on a pro rata basis. This means that you will be responsible for paying a portion of the cost. The Uniroyal tire retailer will determine the portion for which you will be responsible by multiplying the percentage of the original usable tread worn, by the current selling price of the replacement tire at the adjustment location.* You also will be responsible for paying in-full the cost of mounting and balancing the tire, and the cost of any other service charges and applicable taxes.

Treadwear

If a tire is covered and wears out evenly across the face of the tread before delivering the warranted mileage, Uniroyal will replace the tire with a comparable new Uniroyal replacement tire on a pro rata basis. This means that you will be responsible for paying a portion of the cost. The Uniroyal tire retailer will determine the portion for which you will be responsible by multiplying the percent of mileage received by the current actual selling price at the adjustment location or the price of the tire in the current Uniroyal Base Price List, whichever is lower. You will be responsible for paying in-full the cost of mounting and balancing the tire, and the cost of any other service charges and applicable taxes.

Tires which wear out evenly before delivering the warranted mileage will be replaced on a pro rata basis only if:

- 1) You are the original purchaser of the tires, you own the vehicle on which they were originally installed, and the tires have been used only on that vehicle.
- 2) The tires have been rotated and inspected every 10,000 to 12,000 km or as specified by your vehicle manufacturer, whichever rotation period is less, and the attached Mounting and Rotation Service Record has been fully completed and signed.
- 3) The completed Service Record form, Original Owner/Tire Installation Information form, and the Original Invoice are presented to a participating Uniroyal tire retailer at the time of adjustment claim.
- 4) The tires have not become unserviceable due to a condition listed under WHAT IS NOT COVERED.

*Alternatively, membership clubs may multiply the percentage of the original usable tread worn by the actual price paid by the consumer for the warrantable tires (including any instant rebates or promotions).

HOW DO I GET A REPLACEMENT?

Take your tire to any Uniroyal® tire retailer. The retailer will require that you provide one or more the following:

1. The vehicle on which the tire was used,
2. Personal identification (e.g. Driver's License),
3. Your vehicle registration,
4. Payment if you owe a pro rata share for the replacement,
5. A completed Service Record form, and Original Owner/Tire Installation Information Form,
6. Your original invoice and copy of this Owner's Manual, and/or
7. For treadwear replacement claims, documents showing that your tires have been rotated and inspected every 10,000 to 12,000 km or as specified by your vehicle manufacturer, whichever rotation period is less, and the attached Mounting and Rotation Service Record has been fully completed and signed.

WHAT CONDITIONS AND EXCLUSIONS APPLY?

This warranty does not provide compensation for loss of time, loss of use of vehicle, inconvenience or consequential damage. Some provinces do not allow the exclusion or limitation of incidental or consequential damages, so these limitations or exclusions may not apply to you.

This warranty limits the length of all express and implied claims. Some provinces do not allow limitations on how long an implied warranty lasts, so this limitation may not apply to you.

Tires presented for claim remain the property of the consumer, and Uniroyal is not responsible for loss of or damage to tires which are in the custody or control of a Uniroyal tire retailer for the purpose of inspection for warranty claims. In the event of a disputed claim, the consumer must make the tire available for further inspection. Tires accepted for claim become the property of Uniroyal.

No Uniroyal representative, employee or retailer has the authority to make or imply any representation, promise or agreement, which in any way varies the terms of this warranty. These limited warranties apply only in Canada and the United States.

This warranty gives the user specific legal rights, and the user may also have other rights which vary from province to province.

TIRE SAFETY AND MAINTENANCE

THE IMPORTANCE OF MAINTAINING SAFE TIRES

The tire is the only contact between your vehicle and the road surface. Following the inspection and maintenance instructions in this owner's manual is critical to help ensure safe use and longer tire life. Visit the "Tires Care" page at uniroyal.ca for more information about the important safety instructions and procedures in this owner's manual.

SAFETY MAINTENANCE INFORMATION

Read this Owner's Manual, the information on the sidewall of your tires, your vehicle owner's manual and the tire information placard that came on your vehicle, for essential safety and maintenance information.

While you should have complete confidence in your new Uniroyal® tires, it's important to register your tires so we can contact you about any new safety developments. For online tire registration, visit uniroyal.ca.

TIRE FAILURE – SAFETY WARNING

Damage, improper inflation, overloading, a crack, a bulge or other distortion, or other conditions resulting from use or misuse. Tire failures, such as a rapid air loss or a tread and belt detachment, may increase risk of injury or death or property damage. To reduce the risk of a tire failure, you should thoroughly read and follow the instructions in this owner's manual, your vehicle owner's manual, the tire information placard on the vehicle (located in the vehicle's door jamb, inside the fuel hatch, or on the glove compartment door), and tire sidewall information regarding safety warnings, proper tire use and maintenance.

CONTROLLING A VEHICLE WHEN A TIRE FAILURE OCCURS

If a tire failure occurs, you may hear a loud noise, feel a vibration, or feel the vehicle pull toward the side of the failed tire. If that happens, DO NOT BRAKE OR ABRUPTLY TURN THE STEERING WHEEL. Instead, slowly remove your foot from the accelerator and hold the steering wheel firmly while steering to remain in your lane. Once the vehicle has slowed and is fully in your control, apply the brakes gently, safely pull over to the shoulder, and come to a stop in the safest location possible. Inspect all tires. If any tire looks flat or low, or shows detachment or any other damage, replace the wheel and tire with a properly inflated spare after first inspecting the spare for visible damage. Bumps, bulges, or cracks in any tire may indicate detachment within the tire body and require inspection by a qualified tire professional. If any tire, including the spare, has bumps, bulges, cracks, or other visible damage, do not resume driving with that tire. If you have no other option, you should drive as slowly and cautiously as possible until you can obtain towing or mechanical assistance. If the spare tire is not properly inflated, do not resume driving with that tire unless you have no other option, in which case you should drive only as slowly as is safely possible in the traffic conditions until you can both get the spare tire properly inflated and have it checked by a tire professional to ensure that it is safe to use.

PROPER INFLATION

 WARNING	DO NOT DRIVE UNNECESSARILY ON IMPROPERLY INFLATED TIRES.
---	---

DRIVING ON ANY TIRE THAT DOES NOT HAVE THE CORRECT INFLATION PRESSURE IS DANGEROUS

Any underinflated tire builds up excessive heat that may result in sudden tire failure and an accident. If your tires are those that came as original equipment on your vehicle when it was new, refer to the tire information placard that came with your vehicle, (located in the vehicle's door jamb, inside the fuel hatch or on the glove compartment door), for the recommended operating pressures. For replacement tires, ask your Uniroyal tire retailer for the correct inflation pressure; if you do not, refer to the tire information placard that came on your vehicle (located in the vehicle's door jamb, inside the fuel hatch, or on the glove compartment door), for the recommended operating pressures. These inflation pressures must be maintained at a minimum. Never exceed the Maximum Pressure rating stated on the tire sidewall. Note that proper inflation pressures for rear tires may differ from proper inflation pressures for front tires. The Maximum Pressure rating on the tire is normally not equal to the placard pressure.

CHECK THE COLD INFLATION PRESSURE IN ALL YOUR TIRES, INCLUDING THE SPARE, AT LEAST ONCE EACH MONTH

Failure to maintain correct inflation may result in improper vehicle handling and may cause rapid and irregular tire wear, sudden tire failure, loss of vehicle control, and an accident. Therefore, inflation pressures should be checked at least once each month and always before long-distance trip. This applies to all tires, including sealant types and self-supporting tires, which are as susceptible to losing inflation as any other type of tire if not properly maintained. Pressures should be checked before the tires have been driven on or after they have been allowed to cool down to the ambient air temperature. Driving for even a short distance causes tires to heat up and their inflation to increase, and recommended tire pressures are for tires that have not been heated by recent driving on them.

UNDERINFLATION AND OVERINFLATION MUST BE CHECKED WITH A TIRE PRESSURE GAUGE

Tires must be checked monthly with a tire pressure gauge. It is impossible to determine whether tires are properly inflated by simply looking at them. It is almost impossible to feel or hear when a tire is being run underinflated or overinflated. Use an accurate tire pressure gauge to check tire pressure each month. Small and inexpensive tire pressure gauges are available. You should keep one in your vehicle's glove box or trunk and use it monthly and as otherwise needed.

TIRE PRESSURE MONITORING SYSTEMS (TPMS)

Your vehicle may be equipped with a Tire Pressure Monitoring System (TPMS) that is designed to monitor the pressure of tires mounted on your vehicle and sends a signal to the driver if a tire pressure falls below a predetermined level. A TPMS should not replace monthly manual pressure checks for all four tires and the spare. You should manually monitor and check tire pressure inflation with a pressure gauge. Your tires should have the recommended pressure listed by your vehicle's manufacturer. This information can be found in the vehicle owner's manual and is on a placard located in the vehicle's door jamb, inside the fuel hatch, or on the glove compartment door. If you have a plus-size tires that requires a higher inflation pressure, your tire pressure monitoring system will require re-calibration to new inflation pressure. Refer to your tire dealer/installer of plus-size tires for proper inflation pressure. You should check inflation in all your tires, including the spare, once each month and before every long trip. Regardless whether your spare is a full-size spare or a mini-spare, make sure that it is properly inflated. If the TPMS generates improper monitoring or signals, you should consult your vehicle owner's manual and follow up with your vehicle's manufacturer.

TIRE SPINNING

 WARNING	NEVER SPIN WHEELS ABOVE 55 KM/H. NEVER ALLOW ANYONE TO STAND NEAR A SPINNING WHEEL.
---	--

Do not spin wheels in excess of 55 km/h as indicated on your vehicle's speedometer. Excessive speed in a free-running, unloaded tire can cause it to "explode" from centrifugal force. The energy released by such an explosion may cause serious physical injury or death. Never allow anyone to stand near or behind the spinning tire. When in mud, sand, snow, ice or another slippery conditions, do not engage in excessive wheel spin. Accelerating the motor excessively, particularly with automatic transmission vehicles, may cause a drive tire that has lost traction to spin beyond its speed-enduring capability. This is also true when balancing a drive tire/wheel assembly on the vehicle using the vehicle engine to spin the tire/wheel assembly.

HIGH SPEED DRIVING CAN BE DANGEROUS

Correct inflation pressure is especially important. However, at high speeds, even with the correct inflation pressure, a road hazard is more difficult to avoid and if tire contact is made with it, there is a greater chance of causing tire damage than at a lower speed. Moreover, driving at high speed reduces the reaction time available to avoid accidents and bring your vehicle to a safe stop.

 WARNING	DO NOT DRIVE AT SPEEDS FASTER THAN THE SPEED RATINGS FOR YOUR TIRES. NEVER EXCEED LEGAL SPEED LIMITS OR SPEEDS REASONABLE FOR THE DRIVING CONDITIONS.
--	--

Exceeding the maximum speeds shown on the following page for each type of Uniroyal® tire will cause the tire to build up excessive heat, which can cause tire damage that could result in sudden tire destruction and rapid air loss. Failure to control a vehicle when one or more tires experience a sudden air loss can lead to an accident.

In any case, you should not exceed reasonable speeds as indicated by the legal limits and driving conditions.

SPEED RATING SYSTEM

The speed rating of a tire indicates the speed category (or range of speeds) at which the tire can carry a load under specified service conditions. The speed rating system used today was developed in Europe in response to the need to categorize tires into standardized speeds. A letter from A to Z symbolizes a tire’s certified speed rating, ranging from 5 km/h to above 300 km/h. This rating system (see chart on this page) describes the top speed for which a tire is certified.

When this speed rating system was originally developed, the Unlimited V category of over 210 km/h was the top speed rating a tire could achieve. As manufacturers made more tires that fit into this category, it was necessary to better regulate performance at standardized speeds to help ensure safety. The Limited V category of 240 km/h was then created, and the Z or (Y) speed rating was added as the top speed rating that a tire could achieve. W and Y limited speed symbols have been added as higher speed categories.

Always consult the tire manufacturer for the maximum speed of Unlimited Z or (Y) tires. Speed rating is identified as a part of the tire’s sizing or service description. Exceeding the lawful speed limit is neither recommended nor endorsed.

In the latest attempt to standardize tire designations, all ratings except Unlimited Z, incorporate the speed symbol and load index as the tire’s service description. For example:

205/60R15 91V		
205	=	Section Width in Millimeters
60	=	Aspect Ratio
R	=	Radial Construction
15	=	Rim Diameter in Inches
91V	=	Service Description (Load Index and Speed Rating)

Speed Symbol		Speed (km/h)	Speed (mph)
L		120	75
M		130	81
N		140	87
P		150	94
Q		160	100
R		170	106
S		180	112
T		190	118
U		200	124
H		210	130
V		240	149
W	ZR	270	168
Y		300	186
(Y)		Above 300	Above 186 (consult tire manufacturer)

"Z" Rated Tires

When "Z" appears in the size description with the service description, the maximum speed is indicated by the service description. Examples:

Tire Designation	Maximum Speed
P275/40ZR17	Above 240 km/h*
P275/40R17 93Y	300 km/h
P275/40ZR17 93Y	300 km/h
P275/40ZR17 (93Y)	Above 300 km/h*
*Consult Tire Manufacturer	

For tires having a maximum speed capability above 240 km/h, a "Z" may appear in the size designation.

For tires having a maximum speed capability above 300 km/h, a "Z" must appear in the size designation and the service description must include Y in parenthesis. Example: 275/40ZR18 (99Y). Consult the tire manufacturer for maximum speed when there is no service description.

Consult your Uniroyal® tire retailer for maximum speed capabilities. Although a tire may be speed-rated, no vehicle should be operated in an unsafe or unlawful manner. Speed ratings are based on laboratory tests which relate to performance on the road, but are not applicable if tires are underinflated, overloaded, worn out, damaged, altered, improperly repaired or retreaded. Furthermore, a tire's speed rating does not imply that vehicles can be safely driven at the maximum speed for which the tire is rated, particularly under adverse road and weather conditions or if the vehicle has unusual characteristics. Uniroyal® highway passenger tires that do not have a speed symbol on the sidewall have a maximum speed rating of 170 km/h. Light truck highway tires that do not have a speed symbol on the sidewall of the tire have a maximum speed rating of 140 km/h. Uniroyal® winter tires that do not have a speed symbol on the sidewall or tires with Q symbols have a speed rating of 160 km/h. Winter tires with a speed symbol have a maximum speed rating in accordance with the symbol. The speed and other ratings of retreaded tires are assigned by the retreader and replace the original manufacturer's ratings. IMPORTANT: It is recommended that the replacement tire speed rating be equal or higher than the OEM tire size speed rating. If a lower speed rated tire is selected, then the vehicle top speed becomes limited to that of the lower speed rating selected. The customer must be informed of the new speed restriction and the vehicle's handling may be adversely impacted. REMEMBER...High speed driving can be dangerous and may damage your tires. AND...When driving at highway speeds, correct inflation pressure is especially important.

INSPECT YOUR TIRES AND DO NOT DRIVE ON A DAMAGED TIRE OR WHEEL

**WARNING**

INSPECT AND REPLACE ANY VISIBLY DAMAGED TIRE IMMEDIATELY AFTER STRIKING ANY OBJECT IN THE ROAD.

Road hazards and objects in the road, such as potholes, curbs, glass, metal, rocks, wood, and debris, can damage a tire and should be safely avoided. If your vehicle hits any such hazard or object, however, you should promptly inspect your tires. If you see any damage to any tire or wheel, replace it with a properly inflated spare at once and have your tires, including the spare, inspected by a tire professional.

A tire that hits a road hazard or object can be damaged but not have any visible sign of damage on its surface. A tire damaged by an impact can suddenly fail a day, a week, or even months later. You may not recall having hit an object or a road hazard and may not see any tire damage, but such an event may have damaged one or more of your tires. Air loss, unusual tire wear, localized wear, or vibrations can also be signs of internal tire damage and, accordingly, should be addressed as promptly as are instances of visible tire damage.

If you suspect any damage to your tire or wheel from an impact with a curb, pothole, debris on the road, or any other road hazard or object, or if you feel or hear any unusual vibration, replace the tire and wheel with a properly inflated spare at once and immediately visit a qualified tire professional.

INSPECTION

**WARNING**

DO NOT DRIVE UNNECESSARILY ON A TIRE OR WHEEL WITH ANY VISIBLE DAMAGE.

If you see any damage to a tire or wheel, replace it with a properly inflated spare at once and visit a Uniroyal® tire retailer.

Inspect your tires at least once per month, and immediately after contacting any road hazard or object, such as a curb, a pothole, or debris. When inspecting your tires, including the spare, check the inflation as instructed above. If the pressure check indicates that one of your tires has lost pressure of two pounds or more, look for signs of penetration, valve leakage, or wheel damage that may account for the air loss.

Always look for bulges, cracks, cuts, penetrations, and abnormal tire wear, particularly on the edges of the tire tread. Any of these may be caused by misalignment, contact with road hazards or objects, or improper inflation. If any such damage is found, the tire must be inspected by your Uniroyal tire retailer at once. Use of a damaged tire could result in tire failure and an accident.

All tires will wear out faster when subjected to high speeds, hard cornering, rapid starts, sudden stops, frequent driving on roads that are in poor condition, or off-road use. Roads with holes, rocks, or other objects can damage tires and cause misalignment of your vehicle. When driving on such roads, drive carefully and slowly, and before driving again at normal or highway speeds, examine your tires for any damage, such as cuts, bumps, bulges, penetrations or unusual wear patterns.

TREAD WEAR BARS INDICATE THE LIMIT OF TREAD LIFE

Uniroyal® tires contain “Wear-Bars” in the tire tread grooves at 2/32nds of an inch (1.6 mm). When the tread remaining matches the height of the Wear Bars, your tires must be replaced to ensure tire safety. Tires worn beyond this stage are extremely dangerous. For more information on checking tread depth, visit the “Tires Care” page at uniroyal.ca and read the illustrated how-to information on tire inspection.

LOADING

**WARNING**

DO NOT DRIVE ON OVERLOADED TIRES. DRIVING ON ANY OVERLOADED TIRE IS DANGEROUS.

The maximum load rating of your tires is moulded on the tire sidewall. Do not exceed this rating. Follow the loading instructions of the manufacturer of your vehicle and this will ensure that your tires are not overloaded.

Tires that are loaded beyond their maximum allowable loads for the particular application will build up excessive heat that may result in sudden tire destruction. Do not exceed the gross axle weight rating for any axle on your vehicle.

TRAILER TOWING

If you anticipate towing a trailer, you should visit any Uniroyal tire retailer for advice about the correct tire size and pressures. Tire size and pressure will depend upon the type and size of trailer and hitch utilized, but in no case must the maximum cold inflation pressure or tire load rating be exceeded. Check the tire information placard that came on your vehicle, (located in the vehicle’s door jamb, inside the fuel hatch, or on the glove compartment door) and the owner’s manual supplied by the manufacturer of your vehicle for further recommendations on trailer towing.

WHEEL ALIGNMENT AND BALANCING ARE IMPORTANT FOR SAFETY AND MAXIMUM MILEAGE FROM YOUR TIRES.

**WARNING**

DO NOT DRIVE ON UNEVENLY WORN, OUT OF ALIGNMENT, OR UNBALANCED TIRES.

CHECK HOW YOUR TIRES ARE WEARING AT LEAST ONCE EACH MONTH

If your tires are wearing unevenly, such as the inside shoulder of the tire wearing faster than the rest of the tread, or if you detect excessive vibration, your vehicle may be out of alignment or balance. These conditions not only shorten the life of your tires but adversely affect the handling characteristics of your vehicle, which could be dangerous. If you detect irregular wear or vibration, have your alignment and balance checked immediately. Tires which have been run underinflated will show more wear on the shoulders than in the center of the tread. Read and follow the instructions on tire rotation and replacement below.

TIRE MIXING

 WARNING	DO NOT DRIVE ON IMPROPERLY MIXED TIRES.
---	--

Uniroyal® tires. For best, safe performance, the same size and type of tire should be used on all four wheel positions, and the full size spare should be the same size and type. Before mixing tires of different types in any configuration on any vehicle, be sure to check the vehicle manufacturer's owner's manual for recommendations. It is especially important to check the vehicle manufacturer's owner's manual when mixing, matching, or replacing tires on 4-wheel drive vehicles, as this may require special precautions.

WINTER DRIVING

Tires that meet the U.S. Tire Manufacturers Association (USTMA) definition of snow tires are marked M/S, M+S, or M&S. On such tires, normally referred to as "All-Season" tires, the "M+S" designation is molded into the sidewall. Tires without this notation are not recommended for winter driving in regions that experience winter conditions.

Although all-season tires are designed to provide reliable performance in moderate winter conditions, the use of four winter tires is recommended for optimal performance and may be mandatory in certain jurisdictions. Tires designated for use in severe winter conditions are marked on at least one sidewall with the letters "M" and "S" plus a pictograph of a mountain with a snowflake on it. If such a tire needs to be temporarily replaced with a tire not so marked, you should immediately drive at a safe speed to a Uniroyal tire retailer to have the spare returned to the trunk and replaced on your vehicle by another tire with the letters "M" and "S" and the related pictograph.



TIRE ROTATION AND REPLACEMENT

To obtain maximum tread life, you must rotate your tires. You should rotate your tires every 10,000 to 12,000 km or as specified by your vehicle manufacturer, whichever occurs more frequently. Check your vehicle owner's manual for any recommendations by your vehicle manufacturer. Monthly inspection for tire wear is recommended. Your tires should be rotated at the first sign of irregular wear, even if it occurs before 10,000 km. This is true for all vehicles. When rotating tires with a directional tread pattern, observe the arrows moulded on the sidewall that show the direction the tire should rotate. Care must be taken to maintain the proper turning direction. Some Tire Pressure Monitoring Systems (TPMS) may not recognize that a tire has been moved to a different position on your vehicle. Make certain that your TPMS system is reset, if necessary, so as to correctly identify the location of each tire on your vehicle. Refer to your vehicle owner's manual or your vehicle dealer for this information. Determine whether rotated tires require tire inflation adjustment, because front and rear position tire pressure may vary according to the vehicle manufacturer's specification due to the actual load on that wheel position. Some vehicles may have tires of different size mounted on the front versus the rear axle, and these different tires have rotation restrictions. Always check the vehicle owner's manual for the proper rotation recommendations.

Full-size spare

Full-size spare tires (not temporary spares) of the same size and construction should be used in a five-tire rotation and should be inspected by a tire professional during routine tire inspection. Always have spare tires inspected before installation. Tires are composed of various types of rubber compounds and other materials having performance properties essential to the proper functioning of the tire. These component properties change over time. Always check the inflation pressure of the full-size spare and look for any indication of cracking or other damage immediately before incorporating the spare into rotation. If you see any damage, or if the tire is underinflated, do not resume driving with that tire unless you have no other option, in which case you should drive only as slowly as is safely possible in the traffic conditions until you can both get the spare tire properly inflated and have it checked by a tire professional to ensure that it is safe to use. Follow the vehicle manufacturer's recommended pattern for rotation. If such a recommendation is unavailable, see a qualified tire professional.

Replacement of two tires

All four tires should be replaced at the same time. However, if only two tires are replaced, the new ones should be put on the rear. Deeper tread tires on the rear axle provide better handling, wet grip and evacuate water, thereby helping to avoid oversteer and loss of vehicle stability on wet surfaces. Deeper tread tires on the front axle can improve wet straight line braking and stopping distance. If only two tires are being replaced, Uniroyal® generally recommends they be installed on the rear axle in the absence of a tire service professional's recommendation or consumer's preference to the contrary.

CUSTOMIZATION OF TIRES, WHEELS, OR SUSPENSION ON SUVs AND LIGHT TRUCKS

Due to their size, weight and higher centre of gravity, vehicles such as SUVs and light trucks do not have the same handling characteristics as automobiles. Because of these different characteristics, failure to operate your SUV or truck in a proper and safe manner can increase the likelihood of vehicle rollover. Modifications to your SUV or truck tire size, tire type, wheels or suspension can change your vehicle's handling characteristics and further increase the likelihood of vehicle rollover. Whether your SUV or truck has the original equipment configuration for tires, wheels and suspension or whether any of these items have been modified, always drive safely, avoid sudden, sharp turns or lane changes and obey all traffic laws. Failure to do so may result in loss of vehicle control leading to an accident and serious injury or death.

TIRE ALTERATIONS

 WARNING	DO NOT DRIVE ON ALTERED TIRES.
---	---------------------------------------

Do not make or allow any alterations to be made on your tires. Alterations may prevent proper performance, leading to tire damage which can result in an accident. Tires which become unserviceable due to alterations such as truing, whitewall inlays, addition of balancing or sealant liquids, or the use of tire dressing containing petroleum distillates, are excluded from warranty coverage.

TIRE REPAIRS



WARNING

DO NOT DRIVE ON IMPROPERLY REPAIRED TIRES OR ON MISMATCHED TIRES AND RIMS.

WHENEVER A REPAIR IS NEEDED, IMMEDIATELY SEE YOUR UNIROYAL TIRE RETAILER OR, IF ONE IS NOT READILY AVAILABLE, ANOTHER QUALIFIED TIRE PROFESSIONAL.

If any Uniroyal® tire sustains a puncture, have the tire demounted and thoroughly inspected by a qualified tire professional for possible damage that may have occurred. A tread area puncture in any Uniroyal® passenger or light truck tire can be repaired if the puncture hole is not more than 1/4" (6 mm) in diameter, not more than one radial cable per casing ply is damaged, not more than one radial cable per casing ply is damaged, and the tire has not been damaged further by the puncturing object or by running underinflated. Tire punctures consistent with these guidelines can be repaired by following the U.S. Tire Manufacturers Association's recommended repair procedures.

Repairs of all tires must be of the combined-plug-and-inside-patch type. Your Uniroyal® tires must be removed from the wheel for inspection prior to repair. Plug-type repairs made on a tire that remains mounted on a wheel are improper and can result in an accident. A tire should be removed from the rim and inspected prior to repair. Any tire repair done without removing the tire from the rim is improper and can result in an accident. An improperly repaired tire may cause further damage to the tire by either leaking air or allowing air, moisture, and contaminants to enter the structure of the tire. An improperly repaired tire can fail suddenly at a later date and can result in an accident. Never repair a tire with less than 2/32nds of an inch tread remaining. At this tread depth, the tire is worn out and must be replaced.

STORAGE

Tires contain materials to protect their outer surfaces from ozone and weather checking. As the tire rolls and flexes, those materials continually migrate to the surface, replenishing this protection throughout the normal use of the tire. Consequently, when tires sit outdoors, unused for long periods of time (a month or more), their surfaces become dry and more susceptible to ozone and weather checking, and the casing becomes susceptible to flat spotting. For this reason, tires should always be stored in a cool, dry, clean, indoor environment. If storage is for one month or more, eliminate the weight from the tires by raising the vehicle or by removing the tires from the vehicle. Failure to store tires in accordance with these instructions could result in damage to your tires or premature aging of the tires and sudden tire failure. When tires are stored, be sure they are placed away from sources of heat and ozone such as hot pipes and electric generators. Be sure that surfaces on which tires are stored are clean and free from grease, gasoline or other substances which could deteriorate the rubber. Tires exposed to these materials during storage or driving could be subject to sudden failure.

One reason why your spare tire should be included in the tire rotation schedule is that temperatures in a vehicle's closed trunk, especially in sunny geographical areas, can become high enough so that, over a sustained period, they can cause small cracks or other changes to the properties of a tire stored in the trunk. An accumulation of such changes can weaken the tire and, especially if the tire is not kept properly inflated, make it unsafe to use when it is needed.

PROPER TIRE MOUNTING

Tire mounting can be dangerous and must be done by professionally trained persons using proper tools and procedures as specified by the U.S. Tire Manufacturers Association (USTMA).

Your tires should be mounted on wheels that are the correct size and type and are in good, clean condition. Wheels that are bent, chipped, rusted (steel wheels) or corroded (alloy wheels) may cause tire damage. The inside of the tire must be free from foreign material. Have your tire retailer check the wheels before mounting new tires. Mismatched tires and rims can explode during mounting. Also, mismatched tires and rims can result in dangerous tire failure on the road. If a tire is mounted by error on the wrong-sized rim, do not remount it on the proper rim – scrap it. It may have been damaged internally (which is not externally visible) by having been dangerously stretched and could fail on the highway, resulting in an accident.

Old valves may leak. When new tubeless tires are mounted, have new valves of the correct type installed. Tubeless tires must be mounted only on wheels designed for tubeless tires, i.e., wheels that have safety humps or ledges. Always utilize valve caps capable of containing the tire's inflation, should the valve core leak. The valve cap is the primary seal against air loss. Each tire and wheel assembly should be balanced to ensure proper tire and vehicle performance and to maintain tire warranty coverage. Tires and wheel assemblies that are not balanced may cause steering difficulties, a bumpy ride, and irregular tire wear.

TEMPORARY TYPE SPARE TIRES

When using any temporary-type spare tire, be sure to follow the vehicle manufacturer's instructions.

READING THE DOT

DOT XXXX XXXX XXX (prior to August 2000)

DOT XXXX XXXX XXX ◀ (1990-1999)

DOT XXXX XXXX XXXX (After July 2000 to 2025)

DOT XXXXX XXXX XXXX (transition to 13 digits beginning 2018; in effect for all plants by 2025)

THE DOT

The "DOT" symbol certifies the tire manufacturer's compliance with Transport Canada and U.S. Department of Transportation tire safety standards. Next to the symbol is the tire identification or "serial number". The first two characters identify the plant where the tire was manufactured. The next two characters reflect the tire size. The following one to four digits may be used at the tire manufacturer's option as a descriptive code. The last three characters are numbers identifying the week and year of manufacture. (Example: "O25" means second week of the year of decade, eg.: 1995, 1985, etc.) For the 1990-1999 decade Uniroyal® brand tires are marked with a triangle pointing to the last three numeric characters. Tires produced after July 2000 have an additional digit to identify a given decade. For example, 2800 means the tire was produced during the 28th week of 2000; 0201 during the 2nd week of 2001. If the last digits of your DOT number contain three numeric characters and are not marked with a triangle, consult a qualified tire professional to determine the year of manufacture.

SERVICE LIFE FOR PASSENGER CAR AND LIGHT TRUCK TIRES, INCLUDING SPARE TIRES

Tires are composed of various types of material and rubber compounds having performance properties essential to the proper functioning of the tire itself. These component properties evolve over time. For each tire, this evolution depends upon many factors such as weather, storage conditions, and conditions of use (load, speed, inflation pressure, maintenance, etc.) to which the tire is subjected throughout its life. This service-related evolution varies widely, so that accurately predicting the serviceable life of any specific tire in advance is not possible. That is why, in addition to regular inspections and inflation pressure maintenance by consumers, it is recommended that passenger car and light truck tires, including spare tires, be inspected regularly by a qualified tire specialist, such as a Uniroyal tire retailer, who will assess the tire's suitability for continued service. Tires which have been in use for five years or more should continue to be inspected by a specialist at least annually. Consumers are strongly encouraged to be aware not only of their tires' visual condition and inflation pressure but also of any change in dynamic performance such as increased air loss, noise or vibration, which could be an indication that the tires need to be removed from service to prevent tire failure. It is impossible to predict when tires should be replaced based on their calendar age alone. However, the older a tire, the greater the chance that it will need to be replaced due to the service-related evolution or other conditions found upon inspection or detected during use. While most tires will need replacement before they achieve 10 years, it is recommended that any tires in service 10 years or more from the date of manufacture, including spare tires, be replaced with new tires as a precaution even if such tires appear serviceable and even if they have not reached the legal wear limit. For tires that were on an original equipment vehicle (i.e., acquired by the consumer on a new vehicle), follow the vehicle manufacturer's tire replacement recommendations, when specified (but not to exceed 10 years). The date when a tire was manufactured is located on the sidewall of each tire. Consumers should locate the Department of Transportation or "DOT" code on the tire. The code begins with "DOT" and ends with the week and year of manufacture. For example, a DOT code ending with "2214" indicates a tire made in the 22nd week of 2014.

REMEMBER... TO AVOID DAMAGE TO YOUR TIRES AND POSSIBLE ACCIDENT:

- INSPECT TIRES AT LEAST MONTHLY, AND IMMEDIATELY AFTER STRIKING ANY ROAD HAZARD.
- CHECK TIRE PRESSURE AT LEAST ONCE EACH MONTH WHEN TIRES ARE COLD AND BEFORE EVERY LONG TRIP.
- NEVER UNDERINFLATE OR OVERINFLATE A TIRE.
- NEVER OVERLOAD YOUR VEHICLE AND TIRES.
- ALWAYS OBEY LEGAL SPEED LIMITS AND DRIVE AT A SPEED THAT IS REASONABLE UNDER THE ROAD AND WEATHER CONDITIONS.
- AVOID DRIVING OVER POTHoles, OBSTACLES, CURBS OR EDGES OF PAVEMENT.
- AVOID EXCESSIVE WHEEL SPINNING.
- IF YOU SEE ANY DAMAGE TO A TIRE, REPLACE THE TIRE WITH A PROPERLY INFLATED SPARE AND VISIT A QUALIFIED TIRE PROFESSIONAL AT ONCE.
- KEEP TIRES AND WHEELS PROPERLY ALIGNED, BALANCED, AND ROTATED.
- HAVE MOUNTING AND REPAIRS DONE BY A TIRE PROFESSIONAL.
- IF YOU HAVE ANY QUESTIONS, CONTACT YOUR UNIROYAL TIRE RETAILER.

FAILURE TO OBSERVE ANY OF THE RECOMMENDED PRECAUTIONS CONTAINED IN THIS OWNER'S MANUAL CAN LEAD TO ERRATIC VEHICLE BEHAVIOR OR TIRE DAMAGE, POSSIBLY RESULTING IN AN ACCIDENT.

If you see any damage to your tires or wheels, contact your local Uniroyal® tire retailer, or visit our web site listed below for dealer locations. If further assistance is required, contact:

IN CANADA

1-888-871-7777

or write:

Michelin North America (Canada) Inc.
2500 Daniel-Johnson Blvd., Suite 500
Laval, Quebec
H7T 2P6

or visit:

uniroyal.ca

IN THE USA

1-877-458-5878

or write:

Michelin North America, Inc.
Attention: Consumer Care Department
Post Office Box 19001
Greenville, SC 29602-9001

or visit:

uniroyaltires.com

NOTES:

[illegible]

MOUNTING AND ROTATION SERVICE RECORD

Installed Mileage: _____

DATE OF ROTATION SEASONAL CHANGE	ODOMETER READING	RETAILER'S NAME AND ADDRESS	RETAILER SIGNATURE	PSI (check)

MOUNTING AND ROTATION SERVICE RECORD

Installed Mileage: _____

DATE OF ROTATION SEASONAL CHANGE	ODOMETER READING	RETAILER'S NAME AND ADDRESS	RETAILER SIGNATURE	PSI (check)

**ORIGINAL OWNER/TIRE
INSTALLATION INFORMATION
(to be completed at the time of purchase)**

Please keep in your files for future reference.

Retailer name	
Address	
City	
Province	Postal code

DOT NUMBERS

*Tire 1													
*Tire 2													
*Tire 3													
*Tire 4													
*Tire 5													
*Tire 6													

Tire size and name	
Vehicule make	Vehicule model
Model year	Approximate odometer reading (in kilometers)
	<input type="checkbox"/> 0 - 19,999 <input type="checkbox"/> 20,000 - 39,999
Date of purchase	<input type="checkbox"/> 40,000 - 59,000 <input type="checkbox"/> 60,000 - 79,999
	<input type="checkbox"/> 80,000 - 99,000 <input type="checkbox"/> Over 100,000
Date of removal	Mileage at removal
Retailer name and signature	



REGISTER YOUR TIRES ONLINE AT uniroyal.ca OR SEND US YOUR TIRE REGISTRATION CARD BY MAIL

Fields marked with an asterisk (*) are required.

*Purchaser name (Please print) <input type="checkbox"/> Mr. <input type="checkbox"/> Ms.	
*Address	
*City	
*Province	*Postal code
Email	

Retailer name	
Address	
City	
Province	Postal code

TIRE IDENTIFICATION NUMBERS (12 OR 13 DIGITS)

Tire 1 - Serial # (DOT)												
Tire 2 - Serial # (DOT)												
Tire 3 - Serial # (DOT)												
Tire 4 - Serial # (DOT)												
Tire 5 - Serial # (DOT)												
Tire 6 - Serial # (DOT)												

Privacy protection is important to Uniroyal®. We refer you to our privacy policy posted on our website at uniroyal.ca for more information or contact our Consumer Care department at 1-888-871-7777.

In the unlikely event of a tire recall, Transport Canada requires that the tire manufacturer contacts and notifies every purchaser of the tire being recalled. To accomplish that notification, tire purchasers must register their tires with the manufacturer.



UNIROYAL® TIRES
2500 Daniel-Johnson Boulevard, Suite 500
Laval, Quebec H7T 2P6





Consumer Care
1-888-871-7777
uniroyal.ca